



§§§§§§§§§§
Active Thermal Management

Cool answers to hot problems...

Instructions for installation of the Cool-sat™

The Cool-sat is designed to be placed beneath a satellite receiver (or any other small heat-producing device; we shall use the term "receiver" here for simplicity) with vent openings in the approximate center of the bottom. Its fan, while quiet, is powerful enough to force a gentle stream of air up through the receiver and out the top or side openings, providing a substantial cooling effect. The foam dam around the perimeter forms a seal to direct the air stream up into the receiver, and will prevent air leakage around the sides.

Connect the Cool-sat's power supply to a switched power outlet, or, as many satellite receivers keep some of their circuitry on at all times (even when switched off), you may prefer to leave it running at all times, as its power consumption is minimal.

WARRANTY

Active Thermal Management ("ATM") warrants all Cool-series products against defects in materials and workmanship for a period of one year from date of purchase. We will repair or replace, at our option, any Cool-series product which exhibits a defect in materials or workmanship. The product must be properly packaged and returned prepaid with an ATM return authorization number clearly written on the outside of the shipping carton and with a copy of the bill of sale or ATM invoice to verify the original purchase date.

Our warranty does NOT apply to:

- 1. Shipping damage, either concealed or visible. Claims must be filed with the carrier.**
- 2. Damage caused by improper installation or improper electrical voltage.**
- 3. Any product which has been modified, unless authorized by ATM.**
- 4. Damage caused by corrosion, abrasion, immersion, or severe temperatures.**
- 5. Products which have been subject to abuse, misuse, abnormal usage, or accident.**

These warranties give you specific legal rights, and are subject to any applicable consumer protection legislation. You may also have additional rights which vary from state to state.

No other warranties, expressed, implied, or written, shall apply to this product. ATM will not be responsible for any consequential or incidental damages, loss of property, revenues, or profit, cost of removal, installation, or reinstallation, personal injury, or for any breach of warranty, regardless of how caused.

Active Thermal Management

Distributed in Canada by Artech Electronics Ltd.

1870 St. Regis Blvd., Dorval QC H9P 1H6

Toll Free. (800) 631-6448 • Montreal Line (514) 631-6448 • Fax (514) 421-9469

www.artech-electronics.com • info@artech-electronics.com