



Active Thermal Management

Cool answers to hot problems....

Instructions for installation of the Cool-stack™ rack-mount ventilators, INTAKE & EXHAUST models.

Mount the intake version of the Cool-stack low in the rack, with the fans facing UP. It will draw room air in & force it up. Mount an exhaust-type Cool-stack high in the rack, fans facing DOWN; it will draw heated air up and out of the rack. (When using only 1 Cool-stack, we recommend using the "exhaust" type.)

Connect the outputs of the wall-type power supplies to the DC input jacks at the center of the rear panels. Plug the power supplies into switched outlets or connect the "Trigger in" jacks on the rear panels (next to the DC input jacks) to the 12 volt (30 mA min.) trigger output of your system controller, surround-sound decoder, preamp, etc. , and the power supplies into always-on AC outlets. The pilot lights in the center of the front panels will indicate when the Cool-stacks are on. Room air will circulate from the bottom of the rack to the top.

WARRANTY

Active Thermal Management ("ATM") warrants all Cool-it, shelves, plates, racks and stacks against defects in materials and workmanship for a period of one year from date of purchase. We will repair or replace, at our option, any Cool- product which has a defect in materials or workmanship. The product must be properly packaged and returned prepaid with an ATM return authorization number clearly written on the outside of the shipping carton and with a copy of the bill of sale or ATM invoice to verify the original purchase date.

Our warranty does NOT apply to:

1. Shipping damage, either concealed or visible. Claims must be filed with the carrier.
2. Damage caused by improper installation or improper electrical voltage.
3. Any product which has been modified, unless authorized by ATM.
4. Damage caused by corrosion, abrasion, immersion, or severe temperatures.
5. Products which have been subject to abuse, misuse, abnormal usage, or accident.

These warranties give you specific legal rights, and are subject to any applicable consumer protection legislation. You may also have additional rights which vary from state to state. No other warranties, expressed, implied, or written, shall apply to this product. ATM will not be responsible for any consequential or incidental damages, loss of property, revenues, or profit, cost of removal, installation, or reinstallation, personal injury, or for any breach of warranty, regardless of how caused.

Active Thermal Management

Distributed in Canada by Artech Electronics Ltd.

1870 St. Regis Blvd., Dorval QC H9P 1H6

Toll Free. (800) 631-6448 • Montreal Line (514) 631-6448 • Fax (514) 421-9469

www.artech-electronics.com • info@artech-electronics.com